

**STARTING COLLARS (Cont'd.)**



**# 502 Metal Snap Together Starting Collar**



**# 503ATH Air Tite Starting Collar**

Size	# 502		# 503ATH	
	#502 P/N	CTN	#503AT	CTN
4"	5024	1 ea	503ATH4	24 ea
5"	5025	20 ea	503ATH5	20 ea
6"	5026	20 ea	503ATH6	20 ea
7"	5027	20 ea	503ATH7	18 ea
8"	5028	20 ea	503ATH8	22 ea
9"	5029	20 ea	503ATH9	20 ea
10"	50210	20 ea	503ATH10	16 ea
12"	50212	20 ea	503ATH12	16 ea
14"	50214	20 ea	503ATH14	12 ea
16"	50216	20 ea	503ATH16	8 ea
18"	50218	20 ea	503ATH18	8 ea
20"	50220	1 ea	503ATH20	1 ea
22"	* 503ATH & 503ATD 22 & 24 is Less Gasket		503ATH22*	1 ea
24"			503ATH24*	1 ea



**# 503ATD Air Tite Starting Collar w/Damper**



**# 503SATT0 Air Tite 90° Saddle Take Off**

Size	# 503ATD		# 503SATT0	
	#503ATD	CTN	#503 P/N	Fits Trunk
4"	503ATD4	24 ea	503SATT04	14"
5"	503ATD5	20 ea	503SATT05	14"
6"	503ATD6	20 ea	503SATT06	<b>NOTE</b>
7"	503ATD7	18 ea	503SATT07	14"
8"	503ATD8	22 ea	503SATT08	14"
9"	503ATD9	20 ea	503SATT09	24"
10"	503ATD10	16 ea	503SATT010	24"
12"	503ATD12	16 ea	503SATT012	24"
14"	503ATD14	12 ea	503SATT014	24"
16"	503ATD16	8 ea	503SATT016	24"
18"	503ATD18	1 ea		
20"	503ATD20	1 ea		
22"	503ATD22*	1 ea		
24"	503ATD24*	1 ea		

**NOTE: 503SATT0 Saddle Take Off should only be max of 2" smaller than trunk. Example: 6" Take Off on 8" trunk. Other trunk lines are available - call for a quote.**



**# 503SATT0D Air Tite 90° Saddle Take Off w/Damper**



**Typical Scoop Add-On**

Size	# 503SATT0D		START COLLAR SCOOP ADD-ON	
	#503D P/N	Fits Trunk	Scoop P/N	CTN
4"				1 ea
5"	503SATT0D5	14"		1 ea
6"	503SATT0D6	<b>NOTE</b>		1 ea
7"	503SATT0D7	14"	Add X to	1 ea
8"	503SATT0D8	14"	P/N before	1 ea
9"	503SATT0D9	24"	size, e.g.	1 ea
10"	503SATT0D10	24"	503ATX4,	1 ea
12"	503SATT0D12	24"	503ATDX9,	1 ea
14"	503SATT0D14	24"	etc.	1 ea
16"				1 ea
18"				1 ea
20"				1 ea

**NOTE: Specify trunk size 14" or 16" when ordering 6" 503 Saddle Take Off**