

Lubricant

Lubricant is required on all pipe gaskets.
Below is an estimate based on the number of coupling joints.

<u>Pipe Diameter</u>	<u>Joints/2#</u> <u>0200LU</u>	<u>Joints/8#</u> <u>0800LU</u>
4"	89	356
6"	61	244
8"	43	172
10"	33	132
12"	25	100
15"	20	80
18"	16	64
24"	10	40

<u>Product #</u>	<u>Description</u>
0200LU	2# Tub
0800LU	8# Tub Lube
0459AG	4" gasket
0659AG	6" gasket
0859AG	8" gasket
1065MG	10" gasket

